PARTS LIST

for

Whirlpool CORPORATION

thin twin

WASHER • DRYER LAUNDRY SYSTEM

MODELS LT5100XVW0

▲W—White, N—Almond

TABLE OF CONTENTS

	Page No.
WASHER/DRYER CONTROL PANEL PARTS	2
DRYER PARTS	3-8
WASHER PARTS	9-17
SALES ACCESSORIES	18
MISCELLANEOUS PARTS	19
LITERATURE and OPTIONAL PARTS	19
BURNER ASSEMBLY	20

FSP®

FOR CUSTOMER SATISFACTION ALWAYS USE

FACTORY SPECIFICATION PARTS

FSP®

Whirlpool CORPORATION

Benton Harbor, Michigan.

© 1991 WHIRLPOOL CORPORATION

2-91 Litho in U.S.A.

Part No. 3390394

WASHER/DRYER CONTROL PANEL PARTS

For Models: LT5100XVW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	3387713	Harness, Console Wiring (Automatic) (Includes Illus. 1A, 1B & 1C)
1A	342529	Plug, Terminal (2-Way) (Connects With Main Dryer Harness)
1B	696073	Receptacle, Connector (Connects With Lower Automatic Harness)
1C	352089	Disconnect Block (Connects With Automatic Timer)
2	3347890	Timer, Control (60 Hz.) (Automatic\ Washer)
3	63491	Motor, Timer (60 Hz.)
6	694338	Bracket, Control
7	692993	End Cap, Console (L.H. & R.H.)
8	348689	Screw, End Cap Mounting (4) (6-32 x 3/4)
9	694091	Screw, Mounting (2) #8 Posidrive
10	64093	Switch, Water Level
11	342202	Screw, Tapping (6)
12	660393	Switch, Water Temperature 370145 (Alt.) 370146 (Alt.)
13	693711	Sleeve, Console Lock Screw (2)
14	693151	Spring, Console Lock (2)
15	693710	Screw, Console Lock (2)
16	3388255	Timer, Control (60 Hz.) (Dryer) (Timer Motor Not Serviceable)
17	693175	Strut, Console
18	693169	Switch, Push-To-Start
19	693152	Bumper, Console (5)
20	96435	Screw, Timer Mounting (2)
21	694037	Clip, Console
22	98139	Screw, Dryer Timer Mounting (2) (8-32 x 5/16)
23	3389301	Panel, Control
24	3392730	Knob & Skirt, Dryer Timer
25	3392692	Button, Push-To-Start
26	696347	Knob & Clip, Water Level
27	696347	Knob & Clip, Water Temp.
28	3388185	Dial, Timer
29	3392698	Knob, Timer
31	692983	Lock, Console (2)
32	694419	Buzzer

DRYER FRONT PANEL AND DOOR PARTS

For Models: LT5100XVW0



1	692728	Harness, Door Switch (Includes Illus. 1A)
1A	717253	Plug, Terminal (2-Way) (Connects With Main Dryer Harness)
2	347207	Switch, Door
3	295998	Lever, Door Switch
4		Panel, Front
	692619	White
	692620	Almond
5	685763	Seal, Door
6	695656	Door, Rear
7		Door, Front
	348205	White
	689314	Almond
9	349462	Bearing & Seal
10	685203	Clip, Felt Pad (2)
11	696144	Strike, Panel
12	98129	Screw, Door Switch Mounting (2)
13	343641	Screw, 10-16 x 1/2 (2) (Front Panel To Side Panel)
14	3389441	Catch, Door
15		Handle, Door
	686711	White
	689308	Almond
16	692846	Support Protector
17	693739	Fastener, Push (2)
18	339554	Screw, Console Strut Mounting
19	694091	Screw, Door Mount To Hinge & Panel (10)
20	348023	Hinge & Pin, Door (2)
21	693303	Barrier, Harness

DRYER CABINET AND MOTOR PARTS

For Models: LT5100XVW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	660658	Clamp, Motor Mounting (2)
		343481 (Alt.)
		685441 (Alt.)
2	3391887	Motor, Main Drive (60 Hz.)
3	3388235	Switch, Motor Start
4	3393657	Restrainer, Belt
5	696541	Bracket, Motor
6	3390405	Panel, Rear
7	343641	Screw, 10-16 x 1/2
8	307972	Cover, Terminal Block
9	687128	Screw, 10-16 x 1/2
10		Panel, Side (L.H.)
	692613	White
	692614	Almond
11		Plug, Side Panel (2)
	692790	White
	692791	Almond
12	687261	Wire, Motor Ground
13	308544	Screw, 10-24 x 1/2 (8) (Mounts Dryer To Dryer Supports)
14	695524	Elbow, Upper
15	237823	Clip, Front Panel (2)
16	98234	Clip, Ground
17	696045	Elbow, Lower
20	345675	Belt, Drive
21	3389729	Pulley, Motor (60 Hz.)
22	691366	Idler & Bracket
23	692771	Nut, Idler Bracket To Base
24	697410	Base, Dryer
25	692400	Nut, Push-In
26	692926	Cove, Transition Panel (Black)
27		Panel, Transition
	692933	White
	692934	Almond
28	692641	Top, Dryer
29		Panel, Side (R.H.)
	692607	White
	692608	Almond
30	693145	Latch, Lid
31		Closure, Control Area
	692781	White
	692782	Almond
32	354975	Screw & Washer (3) (Lid Latch Mounting)
33	693304	Screw & Washer (2) (Transition Panel To Closure)
34	690989	Screw, Ground (2) (10-32 x 1/2)
36	357021	Capacitor, Motor Start (Automatic Washer)
37	357030	Clamp, Capacitor
38	343641	Screw, Capacitor Mounting (10-16 X 1/2)
41	686770	Edge, Protector
42	3388580	Cable
43	343641	Screw, 10-16 x 1/2 (2)
44	90296	Clip
45	697438	Clip (2)

DRYER BULKHEAD PARTS

For Models: LT5100XVW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	343641	Screw, 10-16 x 1/2
2	345396	Clip, Air Duct To Bulkhead
3	696529	Air Duct & Cover
4	90767	Screw, 8A x 3/8 (Hex Head)
5	660040	Thermostat, Operating (140~F) (60.0~C) 342812 (Alt.)
8	660036	Thermostat, Heater Box 696707 (Alt.) 341196 (Alt.)
9	3393008	Screw, 10-16 x 1/2
10	337272	Clip, Heater Box To Bulkhead
11	697269	Heater Box (120/240 Volts)
13	339956	Seal, Air Duct To Bulkhead
14	696426	Wheel, Blower
15	9416643	Screw, 10-16 x 1/2 (3) (Fan Scroll To Bulkhead)
16	696658	Seal, Fan Scroll
17	696418	Fan Scroll
18	695240	Screw
20	697440	Harness, Thermostat & Heater (Includes Illus. 20A)
20A	692997	Plug, Multi-Terminal (Connects With Main Dryer Harness)
21	339489	Shaft, Drum Roller (R.H.)
22	695943	Drum, Dryer
23	297936	Ring, Bearing
24	685207	Baffle, Drum (3)
25	690372	Screw, Baffle Mounting (6) (11-16 x 7/8)
26	345648	Seal, Drum Rear
27	697540	Bulkhead
28	348399	Lint Screen
29	685273	Cover, Lint Screen Outlet
30	690997	Tri-Ring (4)
31	347364	Shaft, Drum Roller (L.H.)
32	349241	Roller, Support (2)
33	348197	Washer, Support (4)
34	120377	Nut, 3/8-16 (2)
35	342202	Screw, Tapping (4) (Bulkhead To Base)
36	697435	Harness, Main Dryer Wiring (Includes Illus. 36A, 36B & 36C)
36A	717252	Receptacle, Terminal (2-Way) (Connects With Door Switch Harness)
36B	692998	Receptacle, Multi-Terminal (Connects With Thermostat & Heater Harness)
36C	717315	Receptacle, Terminal (2-Way) (Connects With Automatic Console Harness)
37	693141	Clip, Wiring Harness (3)
38	694018	Cord, Power
38	694415	Strain Relief, Power Cord
39	279457	Wire Kit (For Heater Element Wiring Harness Repair)
40	3388703	Washer, Support
41	279393	Screw Kit (For Terminal Block)
42	279318	Terminal, Tinned & Brass (3) (Includes Illus. 41)
43	690989	Screw, Ground (2) (10-32 x 1/2)
44	3389665	Clip, Harness
45	61894	Heater, Thermostat
46	695240	Screw, 8-18 X 1/2 (2)
47	3392519	Fuse, Thermal
48	359702	Cap, Screw
49	255563	Clip, Strain Relief
50	697439	Clip, Harness To Duct (2)

51	312147	Washer
52	345335	Cover, Manifold
53	347455	Support, Heater Box
54	3387208	Support, Corner Gas
55	697571	Guard, Sock
56	697436	Burner (Refer to Parts Page For Complete Breakdown)

DRYER SUPPORTS AND WASHER CABINET HARNESS PARTS

For Models: LT5100XVW0





WIRING HARNESS PARTS



1	694304	Cover, Channel
2	692647	Support, Dryer (L.H.)
3	343641	Screw, 10-16 x 1/2
4	308544	Screw, 10-24 x 1/2 (8) (Washer Cabinet To Dryer Supports)
5	692646	Support, Dryer (R.H.)
6	3388677	Harness, Upper (Automatic) (Includes Illus. 6A, 6B & 6C)
6a	696074	Plug, Terminal (12-Way) (Connects With Automatic Console Harness)
6b	62889	Plug, Terminal (3-Way) (Connects With Automatic Lid Switch Harness)
6c	62505	Block, Disconnect (Connects With Automatic Washer Motor)
7	3347812	Clip, Wiring Harness (4)
8	696636	Clip, Pressure Switch Hose And Wiring Harness (3)
9	685463	Kit, Wire Grounding
10	9412221	Screw, 8-32 x 1/4 (2) (Motor Ground)
11	90016	Clip, Pressure Switch Hose (2)
12	693141	Clip, Harness
13	696238	Hose, Pressure Switch
14	132848	Screw, 10-24 x 1"
15	22965	Strap, Ground
16	685449	Wire, Ground
17	120361	Nut, 10-24
18		Terminal,
	94613	Male
	94614	Female
19	352088	Terminal, Female
20	358763	Terminal, Female
21	374230	Block, Terminal

WASHER TOP AND LID PARTS

For Models: LT5100XVW0



1	359243	Screw
2		Handle, Lid
	379889	White
	3350562	Almond
3		Lid
	3348018	White
	3348019	Almond
4	384475	Bumper, Lid (2)
5	384458	Hinge, Lid (L.H.)
6	21097	Pad, Lid Hinge (2)
7	3351355	Screw, Lid Hinge Mounting (4)
9	692985	Clip, Spring (2) (Top To Cabinet)
10	54690	Plug, Button (2)
11	384460	Spring, Lid (L.H.) (Includes Illus 10)
12		Top
	384693	White
	384694	Almond
13	19119	Bumper, Lid Hinge (2)
14	21258	Bearing, Lid Hinge (2)
15	354764	Screw & Washer, Lid Switch Shield (2)
16	357913	Strike, Lid Switch
17	384459	Hinge, Lid (R.H.)
18	274707	Screw, Ground (10-24 X 1/2)
19	357347	Actuator,Lid Switch
20	271166	Nut, Ground Screw (10-24)
21	384461	Spring, Lid (R.H.) (Includes Illus. 10)
22	661517	Switch, Lid
		388322 (Alt.)
		3347287 (Alt.)
		359230 (Alt.)
23	90016	Clip, Harness Routing
24	359231	Shield, Lid Switch
25	697381	Harness, Lid Switch
25	62888	Receptacle, Terminal (3-Way) (Connects With Harness)

WASHER CABINET PARTS

For Models: LT5100XVW0



1	356746	Clip, Condenser (2)
2	343641	Screw, 10-16 X 1/2
3	62863	Screw, Mixing Valve Mounting (2) (10-16 X 3/8)
5	358992	Valve, Water Mixing
6	272846	Clamp, Hose
7	692699	Hose, Water Inlet (Siphon Break To Mixing Valve)
8		Cabinet
	696013	White
	696014	Almond
10	696710	Hose, Drain
11	692400	Nut, Push-In (2)
12	660975	Plug, Top To Cabinet
		689587 (Alt.)
		694010 (Alt.)
13	356739	Connector, Hose
14	272855	Clamp, Hose
15	356471	Cap, Siphon Break
16	356363	Siphon Break
17	272861	Clamp, Hose
18	696394	Hose, Water Inlet (Siphon Break To Tub Ring)
21	272858	Clamp, Hose
23	358652	Link, Leveling
24	359364	Clip, Leveling Mechanism (2)
25	98234	Clip, Ground
26	345670	Lock, Top (2)
27		Panel, Front
	692628	White
	692629	Almond
31	3350013	Foam (2)
32	64247	Screw

BRAKE, CLUTCH, GEARCASE, MOTOR, AND PUMP PARTS

For Models: LT5100XVW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	387948	Brake And Drive Tube (Complete) (Refer To Parts Page For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3350114	Clutch (Complete)
6	388190	Band And Lining (Includes Illus. 7 & 8)
7	64177	Spring, Clutch
8	62646	Cap, Clutch Spring (2)
9	389246	Gearcase (Complete)(Refer To Parts Page For Further Breakdown)
10	62735	Screw, 5/16-24 x 3/16 (3) (Gearcase To Tub Support)
11	62611	Plate, Motor Mount To Gearcase
12	98062	Screw, 5/16-24 x 5/8 (2)
13	661560	Coupling, Motor & Isolating
14	3349644	Motor, Main Drive
15	3350070	Clip
16	3351341	Plate, Motor
18	3352492	Pump, Complete
19	62700	Retainer, Pump
20	62850	Switch, Main Drive Motor
21	62691	Grommet, Motor (4)
22	3349637	Retainer, Motor (2)
24	357640	Screw, 10-16 x 5/8 (2)

MACHINE BASE PARTS

For Models: LT5100XVW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	285203	Centerpost Bearing Kit (Incls. Illus. 10, 11, & 12)
3	64137	Shield, Tub
4	388492	Spring, Counterweight
5	3350397	Suspension Assembly (3)
6	63755	Base
10	356934	Seal, Centerpost (2)
11	3347047	Bearing, Centerpost (2)
12	357409	Seal, Centerpost (3)
13	63134	Ring, Sound Deadening
14	98610	Screw, 10-16 X 5/8 (2)
15	63636	Bracket, Counterweight Spring
17	63637	Shield, Tub
18	3351021	Nut, 1/2 - 13 (1)
19	63740	Tub Support and Drum
21	690989	Screw, 10-32 X 1/2 (Grounding)
22	90767	Screw, 8A x 3/8 (4)
23	386011	Screw & Washer (Base To Cabinet)
24	696044	Block, Restraint (2)

TUB AND BASKET PARTS

For Models: LT5100XVW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

(CONTINUED ON)

1	63911	Cap, Agitator
2	358237	Screw & Washer (5/16-24 x 1)
4	3349098	Agitator
5	64175	Tub Ring & Gasket (Includes Illus. 7, 14 & 15)
6	21366	Nut, Spanner
7	64000	Gasket, Tub Ring
8	3351985	Basket
9	63782	Tub
10	389140	Block, Basket Drive
11	696238	Hose, Pressure Switch
12	371502	Clamp, Hose
13	386929	Hose, Tub To Pump
14	352155	Clip, Retaining (2)
15	356398	Tube, Drain Off
16	98005	Screw & Washer (Tub Mounting) (4)
17	383727	Gasket, Centerpost
18	63840	Filter

WASHER WATER SYSTEM PARTS

For Models: LT5100XVW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	285321	Sleeve Kit, Plastic Drain Hose (Contains 2 Sleeves)
2	65349	Clamp, Hose (2)
3	16272	Connector, Straight
4	285320	Siphon Break Kit (Not Included)
5	387325	Hose, Corrugated Plastic Drain (5-1/2 Ft.)
	388418	Hose, Corrugated Plastic Drain (10 Ft.) (Not Included)
6	3350222	Retainer, Drain Hose
7	371504	Clamp, Hose
8	384496	Coupling, Hose
9	370445	Clamp, Hose
10	356739	Connector, Hose
11	660028	Hose, Inlet (2)
		81339 (Alt.)
		366108 (Alt.)
12	285442	Connector Kit, Plastic Drain Hose

GEARCASE PARTS

For Models: LT5100XVW0



GC 212-A

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	389246	Gearcase (Complete)
2	62685	Cover, Gearcase
3	62787	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. oz.) (6 Ml.)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitator
11	63273	Gear, Agitator
12	62619	Washer, Agitator Gear
13	62580	Follower, Cam
14	62581	Cam, Agitator
15	389231	Shaft, Agitator
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389229	Bottom and Pinion, Gearcase
20	62528	Gear, Main Drive
21	285352	Seal, Thrust Plug
22	90864	Screw, Gearcase Cover Mounting (8)
23	95082	Ring, Retaining
24	285292	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral, Assembly
27	62534	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

BRAKE AND DRIVE TUBE PARTS

For Models: LT5100XVW0



8D 313 A

1	387948	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Brake Shoe
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	63748	Spring, Brake
12	62909	Sleeve, Brake Spring
13	661516	Cam, Brake Release
		63023 (Alt.)
		3348288 (Alt.)
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining

SALES ACCESSORY PARTS
(OPTIONAL PARTS NOT INCLUDED)

For Models: LT5100XVW0

LCK 4500



LCK 4600



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	694609	Exhaust Deflector Kit (Complete)
2	687128	Screw, Mounting (2) (10-16 X 1/2) (Hex Washer Head)
1	694646	Side Exhaust Extension Kit (Complete)
2	687128	Screw, 10-16 X 1/2(3) (Hex Washer Head)

MISCELLANEOUS PARTS

For Models: LT5100XVW0



1	692894	Miscelleous Parts Bag
2	16123	Washer, Inlet Hose
3	370445	Clamp, Hose
4	367594	Foot, Front (2)
5	358594	Foot, Rear (2)
6	3347868	Tie, Cable
7	3350222	Retainer, Wire

LITERATURE PARTS

	LIT3390945	Guide, Laundry
	LIT3393149	Instructions, Installation
	LIT3391356	Guide, Use & Care
	LIT697546	Wiring Diagram
	LIT3390394	List, Repair Parts

OPTIONAL PARTS NOT INCLUDED

PAINT,TOUCH UP (1/2 oz.)

	72017	White
	72107	Almond

PAINT PRESSURIZED SPRAY (13 oz.)

	350941	Leveler (Thinner)
	350938	Primer, Gray
	350930	White
	350956	Almond

PAINT,BULK (1 qt.)

	799344	White (Uncut)
	978883	Almond (Uncut)

OIL

	350572	Oil, Gearcase (16 Oz.)

LUBRICANT

	285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)

697436 BURNER ASSEMBLY

For Models: LT5100XVW0

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED, TYPE 3 - MANUFACTURED AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	697436	Burner Assembly 60 Hz.
2	697408	Base, Burner
3	694498	Valve, 60 Hz.
4		Orifice
	234822	Natural Gas
	347744	L.P. Gas
5	697807	Harness
6	694539	Coil, 60 Hz. (Split)
7	694540	Coil, 60 Hz.
8	694424	Leak Limiter
9	694421	Screw, 8-32
10	694538	Bracket, Shunt
11	694422	Spring, Regulator
12	239822	Pipe, Plug
13	694423	Screw
14	339527	Screw, 8-18 x 3/8
15	697361	Burner
16	3348629	Screw #8 (3)
17	660991	Ignitor 686590(Alt.)
18	686593	Screw and Washer 8-32 x 1
19	342202	Screw, 10-16 x 1/4
20	697409	Bracket, Sensor
21	338906	Sensor, Radiant
22	697441	Valve, Shutoff
23	3388638	Nipple, Short
24	3391118	Supply Line (Gas)
25	233076	Nut
26	233077	Pipe

Following Parts Not Illustrated

279243	Conversion Kit Type (1) Natural to Type (3) Manufactured
694580	Conversion Kit (Type 1, 2 & 3) to Type (4) L.P.G.